

Mutagenic effects of madder root in textile dyeing processes



Christoph Hafner, Ismene Jäger, Hydrotox GmbH, D-79111 Freiburg Klaus Schneider, FoBiG GmbH, D-79098 Freiburg H. Iznaguen, Universitätsklinikum Hamburg Eppendorf, D-22527 Hamburg

Introduction

Madder roots (*Rubia tinctorum*) have been used for textile dyeing for many centuries up to the present. It is known that extracts of madder roots contain anthraquinones such as lucidine, whose mutagenic and carcinogenic effects have been described in various publications. To determine the possible environmental and toxicological risks in the dyeing process and for dye house workers and consumers wearing textiles dyed with madder root, bacterial reverse mutation assays with *Salmonella typhimurium* (Ames Test) were performed. Dyeing processes with roots of different origin (Bhutan and Iran) were examined. Root extracts, dyeing baths, wastewater samples and the dyed wools were tested.

Methods

Bacterial Reverse Mutation Assay (Ames Test)

Tests were performed according to the OECD guideline 471 and the Directive 2000/32/EG, B. 13/14 with selected strains (TA98, TA100 and TA1537) with and without metabolic activation (S9). A doubling of the number of revertants compared to the negative control (spontaneous mutation rate), which corresponds to an induction rate (IR)>2, was interpreted as a mutagenic effect of the sample. In testing a concentration-series any dose-dependent effect should be detectable. IR<1 indicates a bacteriotoxic effect of the sample, an interpretation as regards mutagenic effects thereby is not possible.

Sample preparation

- A) Organic root extracts
- B) Organic extracts of pressed cake
- C) Organic extracts of the wool
 - 1 8 g DS (A and D), 5 g DS (F) of the solid samples were extracted by Soxhlett with ethyl acetate and ethyl alcohol. Samples were concentrated to dryness in a rotary evaporator and then taken up in 1 ml DMSO for the Ames Test; 20 and 40 µl DMSO extract were tested; (DS = dry substance)
- D) Aqueous dyeing bath

Adjusting pH-value to 7.0 +/- 0.2 with subsequent sterile filtration (0.45 μm); 1,000 μl was tested;

- E) Organic extracts of the four aqueous root extracts
- F) Organic extracts of the aqueous dyeing baths
- G) Organic extracts of the residual liquids (sewage water)
 - 16 20 ml each was extracted with ethyl acetate;

Samples were concentrated to dryness in a rotary evaporator and then taken up in 1 ml DMSO for the Ames Test; 20 and 40 µl DMSO extract were tested;

H) Eluates of the dyed wool with artificial sweat


1g wool was eluated for 24h with acidic and alkaline artificial sweat solution (according to DIN 54 020 with L-arginine-mono-hydrochloride instead of histidine); Adjusting pH-value to 7.0 +/- 0.2 with subsequent sterile filtration (0.45 μ m);


1.000 and 500 µl were tested;


Lucidine analysis in the organic extracts


Analytics were performed with HPLC according to Westendorf et al. 1988;


Results





















project was supported by the European Commission, Quality of Life and	
nagement of Living Resources Programme, Key Action 4 - Environment and	
alth. The authors of the poster are solely responsible for it. It does not represent	
opinion of the Community. The Community is not responsible for any use that	
tht be made of data appearing therein	

Rubia tinctorum (Madder





Conclusions

- In most samples mutagenic effects
- could be detected in the Ames Test
 Root extracts induced the highest
 number of revertants, extracts of
 dyed wool the lowest
- The effects correlated with the lucidine content detected
- Mutagenicity of madder root origin
- Bhutan was lower than of origin Iran

 Artificial sweat extracts of dyed wool
 with madder root origin Iran indicate
 mutagenic activity
- A potential risk for dye house workers and consumers can be stated
- An environmental risk by wastewater can not be excluded

The project was finished in June 2003. Further information is presented at www.hydrotox.de (downloads).